

1. Flow from creation to submission of an image

When paper advance length is longer than paper width:

Short side binding



Upper application (e.g. Photoshop)

Printer Driver
Create and send output image



Printer
(e.g. Noritsu D502)

Print



Front









Back



Front



Back



When paper advance length is longer than paper width:


Long side binding

Upper application (e.g. Photoshop)

Printer Driver
Create and send output image

Printer
(e.g. Noritsu D502)

Print



When paper advance length is equal to or shorter than paper width:

Short side binding



Upper application (e.g. Photoshop)

Printer Driver
Create and send output image

Printer (e.g. Noritsu D502)



Print

Front





When "binding margin" is configured, Printer Driver is to make an image with white border added.

Back




When "binding margin" is configured, Printer Driver is to make an image with white border added.

Front





When "binding margin" is configured, Printer Driver is to make an image with white border added.




When printing direction is set to "horizontal", rotate image 90 deg.


Back




When "binding margin" is configured, Printer Driver is to make an image with white border added.






When printing direction is set to "horizontal", rotate image 90 deg.




Direction of travel changes due to switch back operation.





Printer rotates image 180 degree.



Direction of travel changes due to switch back operation.



Printer rotates image 180 degree.



When paper advance length is equal to or shorter than paper width:

Long side binding

Upper application (e.g. Photoshop)

Printer Driver Create and send output image

Printer (e.g. Noritsu D502)

Print

Front











Image appears as follows in the preview screen of Printer Driver.




Back








Direction of travel changes due to switch back operation.

Printer rotates image 180 degree.







Front



Direction of travel changes due to switch back operation.

Back



Printer rotates image 180 degree.

